



Simplified Laboratory Energy Cost Calculations

Our clients often ask, "what is the yearly cost to condition one CFM of air?" This is an important figure to know if you are attempting to predict energy usage for a new facility or evaluate the economics of engineering modifications to an existing laboratory such as heat recovery systems or fume hood face velocity controls. You can easily calculate approximate costs if you know four things:

- Heating Degree Days
- Cooling Degree Days
- Average Electrical Costs
- Average Natural Gas or Steam Costs

FACTS:

The costs to condition a CFM of air may be divided into five major categories: heating, cooling, fluid moving, humidification and de-humidification. □

To accurately predict these costs, many consultants simulate the building, mechanical systems and the weather using a computer model. This type of accurate analysis is recommended when

designing a new facility in order to size the mechanical equipment and determine power distribution and emergency generating capacity. If, however you just need a relatively close and conservative figure then there is a simpler way of calculating energy costs. It utilizes the first three components mentioned above, heating, cooling and fluid moving, since these can be easily approximated using simple formulae and data which is easy to obtain. Weather data may be obtained either

through the public library in the reference section under the heading *Local Climatological Data* or directly through the National Oceanic and Atmospheric Administration, U.S. Department of Commerce, National Climatic Data Center, Federal Building, Asheville, NC. Utility costs can be obtained through your local utility, or in the case of a large facility, your plant engineering or power department. □

The first step is to calculate the heating costs. If your heating system uses natural gas apply equation 1. A., if it uses steam apply equation 1.B. □

Next, calculate the cooling costs. See equation 2. □

Third, calculate the fluid moving costs. Use equation 3. □

Finally, combine all of these to get the total cost. See equation 4. □

For example, in Midland, Michigan which has 6847 heating degree days, 555 cooling degree days, an average natural gas cost of \$0.35/CCF, and an average electrical cost of \$0.06/KwH will yield an annual cost of \$2.11 to condition one CFM of air per year. This is shown in example 1. □

CAUTIONS:

Note that these formulas are, in some cases fairly conservative because they only estimate sensible heating and cooling loads and do not take into account latent heat in the form of dehumidification and humidification. Actual costs in most applications and locations will be higher. In hot and humid locations (Florida, Louisiana, etc.) requiring extensive dehumidification and in extremely cold areas (Minnesota, etc.) which require significant humidification this method may yield results as much as 25-30% lower than actual. □

CONCLUSION:

The average four foot benchtop fume hood consumes approximately 800 CFM of air from the laboratory space. In the above example, this one hood, operated in a constant volume fashion, would cost over \$1,800 per year to operate. In a medium sized educational or

<p>Eq. 3.: Fluid Moving Costs Using electricity as the power source for supply fans, exhaust fans, air-cooled condenser fans or cooling tower fans, and hot/chilled water pumps for a medical laboratory mechanical system yields the following:</p> $\text{Cost}_{\text{FLUID MOVING}} \equiv \left(E_{\text{ELECT}} \frac{\$}{\text{KwH}} \right) \left(.746 \frac{\text{Kw}}{\text{Hp}} \right) \left(1.75 \times 10^{-3} \frac{\text{Hp}}{\text{CFM}} \right) \left(8760 \frac{\text{Hr}}{\text{Yr}} \right)$ <p>Combining Terms:</p> $\text{Cost}_{\text{FLUID MOVING}} \equiv \left(E_{\text{ELECT}} \frac{\$}{\text{KwH}} \right) \left(11.4 \frac{\text{KwH}}{\text{CFM} \cdot \text{Yr}} \right)$ <p>Where: E_{ELECT} = Average Electrical Costs</p>	<p>Eq. 1.A.: Heating Costs Using natural gas as the fuel in either direct and assuming an 80% efficiency yields the f</p> $\text{Cost}_{\text{HTG}} \equiv \left(DD_{\text{HTG } 65^{\circ}} \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(E_{\text{GAS}} \frac{\$}{\text{CCF}} \right)$ <p>Combining terms:</p> $\text{Cost}_{\text{HTG}} \equiv \left(DD_{\text{HTG } 65^{\circ}} \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(E_{\text{GAS}} \frac{\$}{\text{CCF}} \right)$ <p>Eq. 1.B.: Heating Costs Using steam as the heat source yields the fo</p> $\text{Cost}_{\text{HTG}} \equiv \left(DD_{\text{HTG } 65^{\circ}} \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(E_{\text{STEAM}} \frac{\$}{100} \right)$ <p>Combining terms:</p> $\text{Cost}_{\text{HTG}} \equiv \left(DD_{\text{HTG } 65^{\circ}} \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(E_{\text{STEAM}} \frac{\$}{100} \right)$
<p>Eq. 4.: Total Costs</p> $\text{Cost}_{\text{TOTAL}} \equiv \text{Cost}_{\text{HTG}} + \text{Cost}_{\text{CLG}} + \text{Cost}_{\text{FLUID MOVING}}$	<p>Where: $DD_{\text{HTG } 65^{\circ}}$ = Heating Degree Days E_{GAS} = Average Natural Gas Cost E_{STEAM} = Average Steam Cost</p>

<p>Example 1. Total Cost</p> $\begin{aligned} \text{Cost}_{\text{TOTAL}} \equiv & \left(6847 \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(0.35 \frac{\$}{\text{CCF}} \right) \left(3.24 \times 10^{-3} \frac{\text{Hp}}{\text{CFM}} \right) \left(8760 \frac{\text{Hr}}{\text{Yr}} \right) \\ & + \left(555 \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(0.06 \frac{\$}{\text{KwH}} \right) \left(.0196 \frac{\text{Hp}}{\text{CFM}} \right) \left(8760 \frac{\text{Hr}}{\text{Yr}} \right) \\ & + \left(0.06 \frac{\$}{\text{KwH}} \right) \left(13.9 \frac{\text{KwH}}{\text{CFM} \cdot \text{Yr}} \right) \end{aligned}$	<p>Eq. 2.: Cooling Costs Using electricity as the power source for a medium sized laboratory yields the following:</p> $\text{Cost}_{\text{CLG}} \equiv \left(DD_{\text{CLG } 65^{\circ}} \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(E_{\text{ELECT}} \frac{\$}{\text{KwH}} \right) \left(2.1 \frac{\text{CFM} \cdot \text{°F}}{\text{Day}} \right)$ <p>Combining Terms:</p> $\text{Cost}_{\text{CLG}} \equiv \left(DD_{\text{CLG } 65^{\circ}} \frac{\text{°F} \cdot \text{Day}}{\text{Yr}} \right) \left(E_{\text{ELECT}} \frac{\$}{\text{KwH}} \right) \left(2.1 \frac{\text{CFM} \cdot \text{°F}}{\text{Day}} \right)$ <p>Where: C.O.P. = Coefficient of Performance = 2.1 $DD_{\text{CLG } 65^{\circ}}$ = Cooling Degree Days E_{ELECT} = Average Electrical Cost</p>
--	--

research laboratory facility with 100 fume hoods of different sizes, the yearly energy costs to operate the facility can exceed a quarter of a million dollars. □

There are many ways to conserve energy in laboratories without sacrificing safety. For example, heat recovery and variable air volume laboratory airflow controls can result in a savings of more than 50% of your annual energy consumption and costs. An experienced laboratory consultant can assist you when building a new facility, renovating an existing facility or examining the options to reduce your operating costs. □

industrial hygiene services to our CUSTOMERS which meet their needs, protect their health, productivity and reduce costs.

The MISSION of SAFELAB Corporation is to glorify GOD. We will do this by providing specialized engineering and

Call us to assist you with:

- Laboratory Planning, Safety, and Design Consulting
- Laboratory Fume Hood Testing and Evaluation Services
- Laboratory Fume Hood Database & Documentation Services
- Laboratory Fume Hood Operator Training Services
- Industrial Ventilation Consulting
- Indoor Air Quality Consulting for Industry, Commercial Buildings, and Hospitals

